

R95C 8-Port 2-Channel Discrete and Analog In-Out IO-Link Hub Datasheet



Technical Information

This guide is designed to help you set up and install the R95C 8-Port 2-Channel Discrete and Analog In/Out IO-Link Hub. For complete information on programming, performance, troubleshooting, dimensions, and accessories, please refer to the Instruction Manual at www.bannerengineering.com. Search for part number 234456 to view the Instruction Manual. Use of this document assumes familiarity with pertinent industry standards and practices.

Overview

The R95C 8-Port 2-Channel Discrete and Analog In/Out IO-Link Hub provides a mix of both discrete input/output and analog input/output functionality distributed to two sets of 4-ports.

Ports 1 through 4 contain the discrete functionality, and Ports 5 through 8 contain the analog functionality. These two sets of ports can be monitored and configured using an IO-Link master.

IO-Link®

IO-Link® is a point-to-point communication link between a master device and a sensor and/or light. It can be used to automatically parameterize sensors or lights and to transmit process data. For the latest IO-Link protocol and specifications, please visit www.io-link.com.

For the latest IODD files, please refer to the Banner Engineering Corp website at: www.bannerengineering.com.

Resources

For more information, see P/N 234458 *R95C-4B4UI-KQ IO-Link Data Reference Guide* and P/N 234457 *R95C-4B4UI-KQ IODD Files*.

Mechanical Installation

Install the R95C to allow access for functional checks, maintenance, and service or replacement. Do not install the R95C in such a way to allow for intentional defeat.

Fasteners must be of sufficient strength to guard against breakage. The use of permanent fasteners or locking hardware is recommended to prevent the loosening or displacement of the device. The mounting hole (4.5 mm) in the R95C accepts M4 (#8) hardware.



CAUTION: Do not overtighten the R95C's mounting screw during installation. Overtightening can affect the performance of the R95C.

Status Indicators

On both sides of the R95C IO-Link hub, Ports 1 through 4 have two matching amber LED discrete output indicators, and Ports 5 through 8 have two matching amber LED analog in/analog out indicators. There is also an additional amber LED indicator on both sides of the converter, which is specific to the IO-Link communication, and a green LED indicator that shows power status.

LED	Indication	Status
Discrete Device Amber LEDs	Off	Discrete In and Out are inactive
	Solid Amber	Discrete In or Out is active
Analog In Amber LED ⁽¹⁾	Off	Analog current value is less than setpoint SP1 OR analog value is greater than setpoint SP2
	Solid Amber	Analog current value is between setpoint SP1 AND setpoint SP2
Analog Out Amber LED	Off	Turns off if written PDO analog value is outside the allowable output range Allowable Voltage Range: 0 V to 10 V. Allowable Current Range: 4 mA to 20 mA.
	Solid Amber	Turns on if written PDO analog value is inside the allowable output range Allowable Voltage Range: 0 V to 10 V. Allowable Current Range: 4 mA to 20 mA.
IO-Link Communication Amber LED	Off	IO-Link communications are not present
	Flashing Amber (900 ms On, 100 ms Off)	IO-Link communications are active
Power Indicator Green LED	Off	Power off
	Solid Green	Power on

⁽¹⁾ **Default Current Values:** SP1 = 0.004 A, SP2 = 0.02 A. **Default Voltage values:** SP1 = 0 V, SP2 = 10 V.

Specifications

Supply Voltage

18 V DC to 30 V DC at 400 mA maximum
(exclusive of load)

Power Pass-Through Current

Not to exceed 4 amps total

Discrete Output Load Rating

200 mA

Analog Input Impedance

Current version: Approximately 250 Ω
Voltage version: Approximately 14.3k Ω

Analog Output Load Requirements

Voltage version = Resistance > 1000 Ω
Current version = Resistance < 500 Ω

Supply Protection Circuitry

Protected against reverse polarity and transient voltages

Leakage Current Immunity

400 μ A

Indicators

Green: Power
Amber: IO-Link communications
Amber: 2x Discrete IN/OUT status
Amber: Analog input value present
Amber: Analog output value in range

Connections

(8) Integral 4-pin M12 female quick-disconnect connectors
(1) Integral 4-pin M12 male quick-disconnect connector

Construction

Coupling Material: Nickel-plated brass
Connector Body: PVC translucent black

Vibration and Mechanical Shock

Meets IEC 60068-2-6 requirements (Vibration: 10 Hz to 55 Hz, 0.5 mm amplitude, 5 minutes sweep, 30 minutes dwell)
Meets IEC 60068-2-27 requirements (Shock: 15G 11 ms duration, half sine wave)

Environmental Rating

IP65, IP67, IP68
UL Type 1

Operating Conditions

Temperature: -40 °C to +70 °C (-40 °F to +158 °F)
90% at +70 °C maximum relative humidity (non-condensing)
Storage Temperature: -40 °C to +80 °C (-40 °F to +176 °F)

Required Overcurrent Protection



WARNING: Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table. Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.
Supply wiring leads < 24 AWG shall not be spliced.
For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (A)	Supply Wiring (AWG)	Required Overcurrent Protection (A)
20	5.0	26	1.0
22	3.0	28	0.8
24	1.0	30	0.5

Certifications



Banner Engineering BV
Park Lane, Culliganlaan 2F bus 3
1831 Diegem, BELGIUM



Turck Banner LTD Blenheim House
Blenheim Court
Wickford, Essex SS11 8YT
GREAT BRITAIN



Product Identification



Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

Document title: R95C 8-Port 2-Channel Discrete and Analog In/Out IO-Link Hub Datasheet
Part number: 234455
Revision: A
Original Instructions
© Banner Engineering Corp. All rights reserved.



234455