



Notes:

- Safe isolation between coil and contacts per DIN EN 50178
- A separator plate (e.g., 209-191) must be used for voltages greater than 250 V between adjacent relay modules and for safe isolation.
- Inductive loads have to be attenuated by an appropriate protective circuit in order to protect relay coils and contacts.



Description	V _N	I _N	Item No.	Pack. Unit	V _N	I _N	Item No.	Pack. Unit
Relay socket with miniature switching relay, for DIN 35 rail	24 V AC	34 mA	788-506	1	24 V AC	34 mA	788-512	1
	115 V AC	8 mA	788-507	1	115 V AC	8 mA	788-515	1
	230 V AC	3.5 mA	788-508	1	230 V AC	3.5 mA	788-516	1

Accessories see pages 50 ... 55

[illegible]